

## 3D-F1E-Front End Installation control board



The adhesive adapter has on the side guides for the exact horizontal positioning.



In the back Part are on the side more guide grooves.



The Insertion of the board must be by inserting the adhesive Adapter. This is important, otherwise the board will be tilted and not in the right position.



Done!

The board is inserted to the limit, the 4 openings lie exactly above the Trimm pots.